



Instructions – Sterno Food Warmer / Hot Box

1. Begin by using four Sternos in the hot box. The four will heat the box to approximately 160° F, depending whether the box is used indoors or outdoors.

2. To increase the temperature, add more Sterno.

Cleaning

Throw away all debris and used Sterno.

Note:

To keep food from drying out, add a pan of water to the bottom of the unit.
Continually opening & closing the doors will cause temperature loss faster than the food warmer can recover.